


### Componenti

C1 - Condensatore variabile  
 C2 - Condensatore variabile  
 C3 - 5000 pF  
 C4 - 10.000 pF  
 C5 - 200 pF  
 C6 - 10 mF - 3 V  
 C7 - 3 pF  
 C8 - 200 pF  
 C9 - 10 mF - 6 V  
 C10 - 50.000 pF  
 C11 - 50.000 pF  
 C12 - 2 pF  
 C13 - 200 pF  
 C14 - 50.000 pF  
 C15 - 10 mF - 3 V  
 C16 - 30 mF - 3 V  
 C17 - 10 mF - 3 V  
 C18 - 30 mF - 3 V  
 C19 - 100 mF - 6 V  
 C20 - 0,1 mF

C21 - 100 mF - 6 V  
 C22 - 5000 pF  
 R1 - 22.000 ohm  
 R2 - 10.000 ohm  
 R3 - 3300 ohm  
 R4 - 5600 ohm  
 R5 - 30.000 ohm  
 R6 - 560 ohm  
 R7 - 5600 ohm  
 R8 - 330 ohm  
 R9 - 5000 ohm  
 potenziometro  
 R10 - 5600 ohm  
 R11 - 22.000 ohm  
 R12 - 560 ohm  
 R13 - 1000 ohm  
 R14 - 5600 ohm  
 R15 - 10.000 ohm  
 R16 - 220 ohm  
 R17 - 5 ohm  
 R18 - 60 ohm

R19 - 220 ohm  
 R20 - 5 ohm  
 R21 - 5 ohm  
 R22 - 5600 ohm  
 R23 - 1000 ohm  
 R24 - 220 ohm  
 X1 - 2T7  
 X2 - 2T7  
 X3 - 2T7  
 X4 - 2T6  
 X5 - 2T6  
 X6 - 2T8 o 2T6  
 X7 - 2T8 o 2T6  
 D1 - Diodo 1T23G  
 D2 - Varistors IT51  
 IFT1 - Media Frequenza  
 IFT2 - Media Frequenza  
 IFT3 - Media Frequenza  
 T1 - Trasn. entrata  
 T2 - Trasn. uscita  
 SP - Altoparlante 12 cm.  
 8 ohm



## SONY - TR 712